

FLOW CURVE EQUATIONS - room temperature, quasi-static conditions (strain rate is 1/s or smaller)

Parameters of the constitutive equation: $\sigma_f = C_1 + C_2 \varphi^n + C_3 \exp(C_4 \varphi)$

Data are measured by Department of Material Science and Technology

[illegible]